



Flamefighter Corporation
208 Industrial Blvd., Waconia, MN 55387
Bus: (952) 442-2977
Fax: (952) 442-4106
www.flamefighter.com

Installation Instructions

NFPA COMPLIANT RESTRAINT STRAP #14000

1. The bracket must be bolted to the truck body or seat with no less than a Grade 8 Bolt, with shake proof nuts or washers.
2. The routing of the release lanyard can be under the seat, along side of the seat or overhead. Use the nylon guide loops that are included to route the lanyard where it will be easy to reach.

